

Radiation Products Design Inc

INSTRUCTIONS

RPD INFORMATION

Address 5218 Barthel Industrial Drive

Albertville, MN 55301

Website www.rpdinc.com
Email sales@rpdinc.com

Phone 763-497-2071 or 800-497-2071

Fax 763-497-2295

RPD PRODUCT INFORMATION

Item Number	Description
879-520-RENTAL	RENTAL UNIT Air Sampling Pump Kit, Weekly Rental Fee
879-525	Air Sampling Filter ONLY, One Per Test
879-522	Testing of Sample Filter, Cadmium & Lead

PACKAGE INCLUDES

HFS113A Air Sampler

Air Monitoring Filter

Charger

Tubing

Collar Clip

• FORM 879-520

TO CHARGE THE SAMPLER

- Make sure the sampler is off.
- Plug the charger into an AC outlet and then connect to the sampler.

TESTING A ROOM

SET UP PROCEDURES

- Use fully charged Air sampler.
- Remove red plug from filter and attach tubing over nozzle.

OPERATION

- If charging prior to use, unplug charger prior to testing.
- · Remove blue plug from filter.
- Using a small screwdriver or pen tip, turn the unit on by pushing the ON/OFF switch upwards to the "ON" position.
- Operate test up to 8 hours of continuous testing.
- Upon completion of test, record the room number and time tested (for each sample taken) on FORM 879-520.
- Slide the button to OFF.
- Remove tube from filter and attach red and blue plugs.
- Recharge air sampler if taking another sample.
- Once the samples have been completed, return all items including FORM 879-520 to RPD.

TESTING AN INDIVIDUAL

SET UP PROCEDURES

- Use fully charged Air sampler.
- Remove red plug from filter and attach tubing over nozzle on clip end.
- Attach air sampler to side of individual's hip.
- · Attach clip to collar area.

OPERATION

- If charging prior to use, unplug charger prior to testing.
- · Remove blue plug from filter.
- Using a small screwdriver or pen tip, turn the unit on by pushing the ON/OFF switch upwards to the "ON" position.
- Operate test up to 8 hours of continuous testing.
- Upon completion of test, record the room number and time tested (for each sample taken) on FORM 879-520.
- Slide the button to OFF.
- Remove tube from filter and attach red and blue plugs.
- Recharge air sampler if taking another sample.
- Once the samples have been completed, return all items including FORM 879-520 to RPD.

End of Document