

# TLD ANNEALING PLANCHET

Item 159-000

Before using, remove plastic cover and bake planchet for four hours at 400° C.

To clean holes, use Q-tip swab.

For placing chips, we recommend our Vacuum Tweezer, Item 162-000.