



Radiation Products Design, Inc.

**Item 693-083 or 693-085
Leveling Plate with Anti-Skid Feet**

Leveling Legs Assembly Instructions

The Leveling legs need to be assembled on the plate before using.

1. Install threaded rod/knob assemblies through the plate.
2. Place 1 drop of #242 Loctite inside the threaded hole of the leveling pad. Screw the leveling pad onto the threaded rod and tighten with a wrench.
3. To make the leveling legs raise/lower easier, put a light coat of grease or vaseline on the threaded rods.

The unit is then ready for use.

**5218 Barthel Industrial Drive NE – Albertville, MN 55301
Phone: 763-497-2071 or 800-497-2071 Fax: 763-497-2295**