

TLD POLYSTYRENE EASY-TRANSFER CASE ITEM 163-010

DO NOT PLACE STORAGE HOLDER IN FURNACE.

For Placing Chips In Easy-Transfer Case:

1. Remove screws securing top plastic cover from the aluminum planchet.
2. Remove acrylic cover from the Easy Transfer Case.
3. Place the polystyrene Easy Transfer Case on the top of the aluminum planchet with the numbers in proper orientation (can be resecured with screws), then turn over - tap bottom so TLD chips will fall into adjoining holes.
4. Replace top covers on Easy Transfer Case and planchet to retain chips.
5. To clean holes, use Q-Tip swab.