



**Expect Service**

**Radiation Products Design Inc**

---

## INSTRUCTIONS


---

### RPD INFORMATION

<b>Address</b>	5218 Barthel Industrial Drive Albertville, MN 55301
<b>Website</b>	<a href="http://www.rpdinc.com">www.rpdinc.com</a>
<b>Email</b>	<a href="mailto:sales@rpdinc.com">sales@rpdinc.com</a>
<b>Phone</b>	763-497-2071 or 800-497-2071
<b>Fax</b>	763-497-2295

### RPD PRODUCT INFORMATION

<b>Item Number</b>	<b>Description</b>
878-275	Island Blocking Device, 10" (25.4cm)



## INTRODUCTION

This device is intended to form shielding alloy to specific shapes.


## WARNING

- Use foam only on flat surfaces to avoid alloy leakage.
- Do not pour molten alloy onto island blocking device.
- Allow alloy to cool to room temperature before removing devices.

## INSTRUCTIONS

Using flat electron foam

1. Trace shape representing tumor area onto foam.
2. Cut out traced shape.
3. Attach island blocking device (if applicable).



4. Begin shielding alloy casting process as dictated by casting protocol.

## DISPOSAL

- Users of this product have an obligation and responsibility to provide the highest degree of safety hazard control to co-workers and themselves. To avoid safety hazards, wear all recommended protective equipment and follow safety control policies established by your facility.
- Ensure device is free of alloy before disposal.

**End of Document**